

Raised Garden Bed White Oak Construction Plan

Raised Garden Bed Supply list

Lumber

White Oak 1 1/2"x10" - linear feet of lumber will vary per the size of your garden bed.

Hardware

Lag Screws, galvanized 3/8" x 4" – quantity 8

Washers, galvanized 3/8" - quantity 8

Tools

Electric drill

Circular saw


Carpenter's square

Spade drill bit – 1 1/4"

5/16" auger drill bit

Socket wrench for 3/8" lag screws (9/16" with ratchet handle)

2 lag screws
and washers
per corner



Countersunk holes for the lag screws should be 2" from the top and bottom of board and deep enough so the lag screw head is flush with the front surface of the board.

Note: For the lag screw to be able to draw the corner boards tightly together a washer must be used.

